



FIG. 1  
(STABLE SOIL)

FIG. 2  
(SEMI-STABLE SOIL)

GENERAL NOTES:

BEDDING MATERIAL IS USED IN ALL CASES FOR "HAND BACKFILL" AREAS.

TRENCH BRACING TO CONFORM TO THE ADMINISTRATIVE CODE.  
BACKFILL TRENCH UP TO WATER SERVICE PIPE, AND SUBSTANTIALLY  
FLUSH BACKFILL BEFORE PLACING WATER SERVICE.

BACKFILL TRENCH UP TO BUILDING STORM SEWER AND SUBSTANTIALLY  
FLUSH THE BACKFILL BETWEEN BUILDING STORM SEWER AND WATER SERVICE  
BEFORE PLACING BUILDING STORM SEWER.



City of Oak Creek  
Department of Public Works

Drawn By: K.C. Seufzer

Scale: Not to Scale

Appv. By: M.J. Sullivan

Date: 10/1/98